

# Equipment Pad

## Installation Guide

### Instructions for Replacing an Enclosure with Conduits already installed

#### Required Items

- Equipment Pad
- Hand Tamper
- Shovel
- 48" Level

#### 1. Site Preparation And Installation

- 1.1.** Locate the conduits and level the area where the pad is to be placed.
- 1.2.** If the installation location is on a slight hillside, the hillside must be excavated. Use minimal fill dirt and compact any fill dirt used.
- 1.3.** Tamp all disturbed dirt, especially in the trench area.
- 1.4.** Make sure that the contact area for the pad is level and set the pad, ensuring complete contact between the soil and the bottom of the pad.

